Setting up PRO M + App download

1. Power on device, press Start
2. Insert SIM if you have one, skip if not
3. Connect to your Wi-Fi
4. Don’t copy apps and data
5. Sign into your Google account
6. Turn off ‘Use basic device backup’, press Accept
7. Choose Google as Search provider
8. Skip PIN code set up
9. Skip Hey Google Assistant
10. Skip Google Pay
11. Anything else? – No thanks
12. If you are adding any apps, open the Google Play Store
    The Webfleet Work App and TomTom Go Fleet apps are pre-installed
13. Search for app, press Install